

User manual

Fryer ADV

Type Code ADF-21



FKI Fast Food Teknik a/s

Version 12.0

Contents

1	Introduction	3
1.1	General	4
1.1.1	Appliance description	4
1.1.2	Manufacturer	4
1.1.3	Appliance label	4
1.1.4	Technical specifications and power consumption	4
1.1.5	Modification	5
2	Safety	6
2.1	Personal safety equipment	6
2.2	Potential hazards	6
2.3	Safety measures, integrated	7
2.4	Safety functions	7
2.5	Who may use the appliance	7
2.6	Transport/installation/fixation	8
2.6.1	Transport	8
2.6.2	Installation	9
2.6.3	Fixation	10
2.7	Operation	10
2.8	Cleaning/maintenance	10
2.9	Servicing	10
3	Operation	11
3.1	Before first use	11
3.2	Filling with oil	11
3.3	Quick start instructions	11
3.4	Start-up	12
3.5	Programming	13
3.5.1	Setting the individual programs	13
3.5.2	Settings that apply to all programs	15
3.5.3	Temperature and operating zone configuration	15
3.5.4	Setting the sound	17
3.5.5	Password setting	17
3.6	Operation	18
3.7	Error codes	21
3.8	Operation of oil cleaning system Fryer ADV (optional product)	22

3.8.1	Programming oil cleaning	24
3.8.2	Preparation of the filter system.....	25
3.9	Spare parts.....	27
3.9.1	Spare parts list	28
3.9.2	Spare parts list Automatic Raise/lowering for Fryer ADV SF	30
3.9.3	Spare parts list Automatic Raise/lowering for Fryer ADV DF	31
3.9.4	Spare parts list Automatic Raise/lowering for Fryer ADV SFS	32
3.9.5	Spare parts list oil cleaning system.....	33
3.9.6	IT-system.....	35
4	Electrical diagram	36
4.1.1	Fryer ADV 400V 3N~ / Fryer ADV 230V 3~ (Overview).....	36
4.1.2	9kW, 15kW, 21kW	37
4.1.3	Single controller.....	38
4.1.4	Heating section	39
4.1.5	Single oil clean	40
4.1.6	Double oil clean	41
4.1.7	2x5kW, 2x7kW	42
4.1.8	Split controller	43
4.1.9	Split heating section	44
4.1.10	Split oil clean.....	45
4.1.11	Component overview Fryer ADV 400V 3N~	46
4.1.12	Component overview Fryer ADV 230V 3~.....	47
4.1.13	IT System 400V 3~	48
4.1.1	Component overview IT System 400V 3~	57
4.2	General	58
4.3	Cleaning during operation	58
4.4	Daily cleaning.....	58
5	Service	61
6	Disposal.....	63
6.1	Packaging	63
6.2	When the appliance is no longer required	63
7	EU DECLARATION OF CONFORMITY	64

1 Introduction

Original user instructions

These instructions are FKI Fast Food Teknik's original instructions for appliance FRYER ADV.

The purpose of these instructions

These instructions are intended to ensure the correct installation, use, handling and maintenance of FRYER ADV.



Important! Read these instructions carefully before use and keep them safe for later use.

Storage of these instructions

You must retain these instructions and make sure that they are easily accessible to users and service technicians.

Understanding these instructions

It is the responsibility of the Appliance's owner to ensure that anyone who will be operating, servicing, maintaining or repairing FRYER ADV has read these instructions and, by way of minimum, the sections that are of relevance to the work they will perform.

Anyone who will be operating, servicing, maintaining or repairing FRYER ADV is required to look up any relevant information in these instructions.

1.1 General

1.1.1 Appliance description

Fryer ADV is an easily programmable fryer that is easy to operate and maintain. Fryer ADV has deep oil vats, so removable splash covers are not required. The powerful heating elements and electronic temperature sensor heat the frying oil very quickly. Fryer ADV is easy to clean. Fryer oil temperature is shown on a display that can be programmed with up to six fry times. An automatic raise/lower system is an optional upgrade.

1.1.2 Manufacturer

FKI Fast Food Teknik a/s
Byghøjvej 5, Vernerup
DK-5690 Tommerup
www.fki.dk

1.1.3 Appliance label



Type code: ADF-21

1.1.4 Technical specifications and power consumption

1.1.4.1 Dimensions and weight

Description		Vat	Dimensions (BxDxH)	Weight
FRYER ADV	SINGLE TABLE	16L	352x655x370	32 kg
FRYER ADV	SINGLE TABLE SPL	2x10L	470x655x370	41 kg
FRYER ADV	DOUBLE TABLE	2 x 16L	705x655x370	60 kg
FRYER ADV	SINGLE FLOOR	16L	352x655x880	44 kg
FRYER ADV	SINGLE FLOOR SPL	2x10L	470x655x880	57 kg
FRYER ADV	DOUBLE FLOOR	2 x 16L	705x655x880	99 kg

1.1.4.2 Power

Description		Vat	Voltage	Power	Current	Min. fuse rating for installation
FRYER ADV	SINGLE FLOOR	16L	400V	9kW	13.0A	16A
FRYER ADV	SINGLE FLOOR	16L	3x230V	9kW	22.6A	25A
FRYER ADV	SINGLE FLOOR	16L	400V	15kW	21.6A	25A
FRYER ADV	SINGLE FLOOR	16L	3x230V	15kW	37.6A	40A
FRYER ADV	SINGLE FLOOR	16L	400V	21kW	30.3A	32A
FRYER ADV	SINGLE FLOOR SPL	2x10L	400V	10kW	21.6A	25A
FRYER ADV	SINGLE FLOOR SPL	2x10L	3x230V	10kW	37.6A	40A
FRYER ADV	SINGLE FLOOR SPL	2x10L	400V	14kW	30.3A	32A
FRYER ADV	DOUBLE FLOOR	2x16L	400V	2x9kW	13.0A	2x16A
FRYER ADV	DOUBLE FLOOR	2x16L	3x230V	2x9kW	22.6A	2x25A
FRYER ADV	DOUBLE FLOOR	2x16L	400V	2x15kW	21.6A	2x25A
FRYER ADV	DOUBLE FLOOR	2x16L	3x230V	2x15kW	37.6A	2x40A
FRYER ADV	DOUBLE FLOOR	2x16L	400V	2x21kW	30.3	2x32A

*Actual measured result can be expected to be lower.



The appliance should be connected to its own circuit.

1.1.4.3 Intended use

The fryer is intended for deep frying in oil/fat of defrosted and frozen products that are suitable for deep frying.

The fryer must never be used for purposes other than deep frying food.

1.1.5 Modification

FRYER ADV must **never** be modified or serviced by unauthorised persons. In the event of non-compliance, FKI Fast Food Teknik a/s waives any and all liability.

2 Safety

General

Read these safety instructions before using the appliance. Keep them near to the appliance for later reference. These instructions and the appliance itself are provided with important safety information that must always be read and observed at all times. FKI Fast Food Teknik a/s disclaims any and all liability for non-compliance with these safety instructions, for inappropriate use of the appliance or the use of incorrect settings.

Fryer ADV has an electronic user interface with the option of programming with a touch-sensitive screen and running daily programs using push buttons for tactile feedback. Precise adjustment using an electronic controller. Also with USB port to quickly program multiple machines.

FRYER ADV is designed for continual deep frying of various food products. The appliance can also be used for other foods that are suitable for frying. To determine optimum temperature and time, a test fry is always recommended before commencing series production. Note that the nature of the food (thickness, temperature, surface, etc.) will affect the frying result.

When running, the appliance must be continually monitored by staff who have been trained and instructed in how to use it.

2.1 Personal safety equipment



It is recommended that gloves and goggles are worn when working with the fryer and when emptying the vats as the fryer has hot surfaces and hot grease can be dangerous.

2.2 Potential hazards



Surfaces on the fryer's tabletop and vats are hot and must not be touched when switched on.



Therefore, be careful not to touch them while operating the fryer.


During operation, only the buttons and the touch screen on the front may be touched. The food for preparation should be placed in the basket when it is in the basket retainer. The basket should then be carefully lowered into the oil.

Avoid touching the fryer's hot surfaces.

2.3 Safety measures, integrated



The heating section has an integrated magnetic contact to cut power to the heating elements if the heating section is removed from the top panel. The electronic control system is fitted with an acoustic alarm that will activate when temperatures exceeding 200°C are registered.




2.4 Safety functions



The heating section has an integrated safety thermostat that will cut power to the heating elements if temperatures exceed 230°C. The thermostat can be reset and connected once the temperature has fallen. To reset the thermostat, press the red button next to the heating section. The electronic control system has a fuse to protect the control system against overload. The fuse is located under the front panel with the display.

We recommend that the fryer is serviced to find out why the safety thermostat was triggered.



2.5 Who may use the appliance



This appliance is not intended for use by children! Neither should it be used by persons with reduced physical or mental capacity, or who lack appropriate experience and knowledge unless they have been trained or instructed in the use of the appliance by someone with responsibility for their safety.

2.6 Transport/installation/fixation

2.6.1 Transport

The fryer is delivered secured to a transport pallet and should only be transported in the same way if moved.

When lifting the appliance into position, lift carefully from the transport pallet by lifting at the front edge of the table top, allowing it to be carefully rolled into position.

WARNING: Do not lift the appliance at the heating sections.



Moving and setting up the appliance must be performed by two or more people due to RISK of injury!

Wear protective gloves and safety footwear during unpacking and installation.
Cut hazard.

2.6.2 Installation

The appliance must be connected to the mains by an authorised electrician.

The fryer must always be connected to ground. Depending on variant, the fryer should be connected to either 400V 3N~ or 230V 3~ via an approved supply isolator. Note that each heat section requires a separate connection.

As standard, floor models are supplied with front legs and fixed wheels at the rear. Space should be left in front of the fryer so it can be pulled away from the wall when cleaning or performing maintenance tasks.



The fryer must be connected by an authorised electrician and connected to an RCCB circuit breaker.

See diagram for correct connection:



WARNING: This appliance must be earthed. Failure to do so may cause electric shock and serious injury.



The appliance must be acclimatised before use. It should therefore not be started up until eight hours have elapsed.



The power supply must be able to be disconnected, either by unplugging or by means of a freely accessible multi-pole switch located before the power outlet in accordance with applicable electricity regulations. **The appliance must be grounded in accordance with national safety standards for electrical appliances.**



Do not use extension cords or multi-socket outlets. After installation is completed there must be no direct access to the electrical components. Never touch the appliance if you are wet or have bare feet. Do not use this appliance if the power cord or plug is damaged, if the appliance is not working properly, if it is damaged or if it has been dropped on the floor.



Any replacement of the power cord must be performed by an authorised technician to avoid the risk of personal injury – RISK of electric shock. Only use oil-resistant cables!

2.6.3 Fixation



The appliance does not need to be secured. It is equipped with wheels and/or adjustable legs to ensure stable and easy installation.

2.7 Operation

The appliance must be supervised during use and must be switched off at its main switch if left.



FRYER ADV is intended for food preparation only. **Never fill the appliance with oil or fat when it is switched on. Oil/fat can ignite if it contacts the heating elements. It can also produce intense smoke.**

2.8 Cleaning/maintenance



CLEANING AND MAINTENANCE WARNING: Check that the appliance is set to the cleaning program before performing daily cleaning or maintenance tasks. Do not use products that contain acid as they may damage the surface of the appliance.



Never use steam/foam cleaners due to RISK of electric shock.

2.9 Servicing



WARNING: The appliance has two supply connections, which must both be disconnected before starting service work on the appliance.



The appliance must always be switched off and disconnected from the power source before commencing repair work.

3 Operation

3.1 Before first use



Before start-up, remove all packaging and protective plastic from the fryer and dispose of it in accordance with currently applicable regulations (see section 6.1). Carefully read section 2 about safety before connecting the fryer.



Before start-up, clean the appliance as shown in section 0.

3.2 Filling with oil



Turn the fryer off. Never fill the appliance with oil or fat when it is switched on. Oil/fat can ignite if it contacts the heating elements. It can also produce intense smoke.

Remove the basket. Now fill the fryer with oil/fat to the correct volume. The fryer must never be switched on unless oil has been filled at least to the minimum level indicator on the inner side of the vat (at the rear).

3.3 Quick start instructions

Before start-up, read section 4.2 under “cleaning”.

Press the cog icon  to program the fryer and adjust temperature settings. (see section 3.5 about programming).

Press start  on the display and wait 30 minutes for the fryer to heat up and become ready for use.


The appliance must not be operated unattended.



Remember to use personal safety equipment, see 2.1

3.4 Start-up

Explanation of the FRYER ADV user interface:



No.	Description
1.	Light
2.	Start
3.	Program buttons
4.	Settings
5.	Screen
6.	Switch
7.	USB port max. 4GB

Turn the switch (6) behind the front door and the light (1) on the front of the appliance will turn on. Press  to turn on the appliance or press  to configure the appliance.

FRYER ADV is supplied with the following factory settings:


Temperature: 170°C

Frying time: 2:40 minutes

Factory settings can be reloaded by creating a blank text file on a USB dongle named "factory.txt" and load the file under USB settings.

After use, always switch the appliance off at the main switch (6).

3.5 Programming




Standby

Press **O** to enter daily operation, see section 0 (during operation only the buttons can be used, not the screen).

Press **S** to go to settings, see section 3.5.1 (in “settings” the touch screen is used instead of the buttons. Here only the “S” button works).

3.5.1 Setting the individual programs




Access control

Entering the settings menu requires entry of a default password, which is shown here on the screen. This can be changed in “password setting” or you can deactivate it. We recommend, however, that password is always enabled.


Forgotten passwords can be reset to the factory setting as follows:

1. Create a blank text file on a USB dongle named "pinreset.txt"
2. Press **S** to enter *standby* mode.
3. Insert the USB dongle into the corresponding USB port.
4. Press **S** to return to *access control*. The password is now reset and is as shown in the picture.



Home screen


This picture shows the home screen in the settings menu. To set one of the six programs, press $\uparrow\downarrow$ next to the program you want to configure.



Program settings submenu

Program 3 is selected. It is now possible to set fry time and program name. Pressing the light bulb icon allows you to deactivate the program if it is not required (settings are stored even if the program is deactivated).


When set for single basket use all six programmes are available. When set for twin basket use the right and left side of the display are dedicated to their respective baskets, so there are only three programmes per basket.



Time setting

Here fry time for Program 3 is selected. When you have selected the correct time, approve it and you will then return to the previous screen.

If a program time setting is 00:00, the timer will function as a *stopwatch* and will count upwards from zero seconds.



Edit program name

Here, the program name is selected. Enter the name you want to use and approve.

3.5.2 Settings that apply to all programs

Explanation of symbols for this section:

	Temperature
	Temperature Operating zone
	Sound
	Password
	USB port
	Switch between single and twin basket setting

3.5.3 Temperature and operating zone configuration



Temperature

If you press “temperature setting” on the home screen, this screen will appear.

Here, you have the option to set the oil temperature, approve the set temperature, and return to the *home screen*.




Operating zone temperature

This picture shows the screen that will appear if you tap this icon


Here you have the option to select a temperature range to ensure that the appliance always fries to perfection. When temperature is outside the selected range, the screen will lock until it is ready again .

The following two pictures show what is displayed on the screen if the appliance is too hot or not hot enough. This option can be changed to show a colour indication in the main menu as to whether the oil in the tub is too hot or too cold .

This allows the user to ignore the warning. It is also possible to completely remove this indication .



Screen if the appliance is not hot enough.



Screen if the appliance is too hot.


3.5.4 Setting the sound



Sound

When adjusting the sound settings, it is possible to set the volume as a percentage, and a time for how long the notification should sound when the program is completed.


3.5.5 Password setting



Password

Here, you have the option to change the password that is required to enter the settings menu, or deactivate the password completely. Deactivate the password by entering an empty password and clicking "OK".

USB dongle




USB port

The USB port allows you to upload programs or save them externally. The icon only becomes active when a USB dongle is inserted. The top USB port is for the left screen and the lower one is for the right screen. The capacity of the USB dongle must not exceed 4GB.

NB! If the USB dongle contains a settings file and the dongle is read or written, the settings will be overwritten without asking for permission.

3.6 Operation




Home screen

This is the home screen during operation.

Press 1-6 to start a program.


Press **O** to switch off or go into *standby*.

Press and hold **S** for 3 seconds to display a graph of the temperature over the last 3.5 hours.




Program active

If program 1-6 is selected on the home screen, this screen will appear. Here, program 2 is selected. This displays time remaining. If you want to stop frying before the set time has expired, press the selected program (here, program 2) and you will return to the *home screen*.




With twin baskets

When using twin baskets, this screen will appear if two baskets are active at the same time.



Timer


This image shows the timer function that operates if time is set to 00:00 in a program and is not adjusted. This is typically used to determine the ideal frying time for a particular food product.



Shutdown

If **O** is pressed on the home screen, you will see this screen, from where you can enter energy saving mode for reduced power consumption, using buttons 3 and 5.


Programs 4 and 6 switch off the appliance when the baskets are in raised or lowered position, respectively. If no selection is made, the appliance will enter *standby* after 15 seconds with baskets lowered.



Energy-saving mode

Here, 75 % heat is selected.

To return to the home screen, press **O**.




Temperature graph

If **S** is held down on the *home screen* for three seconds, this image will appear for about 10 seconds before the screen automatically returns to the *home screen*. The temperature graph shows the temperature for the last 3.5 hours, as well as the current temperature.

If you want to leave this prematurely then press **S**.

3.7 Error codes



Error codes


In the event of a fault in the appliance, an error message like those shown here will appear. Find the error code in the below chart and try to rectify the error or contact service.

ERROR CODE	ERROR	CAUSE	REMEDY	SW version
01	Communication error	Graphical user interface does not respond to control print.	Turn off the power for 10 seconds using the switch on the side of the appliance. If the error persists, contact service.	0.3.0000 ->
02	No status report	The control print does not deliver status reports to the graphical user interface.	Turn off the power for 10 seconds using the switch on the side of the appliance. If the error persists, contact service.	0.3.0000 ->
11	Oil overheated	The solid state relay may have short-circuited.	Contact service.	0.3.0000 ->
13	Temperature sensor error	The measured values are either too high.	Contact service.	0.3.0000 ->
15	Temperature sensor error	The measured values are either too high related to expected values.	The environment is either too cold or the sensor is short-circuited. If sensor is short-circuited, service must be contacted.	0.3.0000 ->
20	Motor 1 overloaded	The motor is worn or there is too much friction on the lever.	Try cleaning the appliance's moving parts. If the error persists, contact service.	0.3.0000 ->
21	Motor 2 overloaded	The motor is worn or there is too much friction on the lever.	Try cleaning the appliance's moving parts. If the error persists, contact service.	0.3.0000 ->


3.8 Operation of oil cleaning system Fryer ADV (optional product)

The oil cleaning program can be accessed in two ways.


1. From off mode, press the setting button "S." After this, select the clean program symbolized by a drop.
2. From active mode, press the off button "O." Then select the cleaning program symbolized by a drop in the upper right corner "2."




Screenshot in off mode



Screenshot after pressing setting button "S" as stated above



Screenshot Active mode



Screenshot with program examples

3.8.1 Programming oil cleaning




There are 4 different programs.

Key "1" is intended for refilling and lasts 1½ minutes.

Key "3" is a short program where the pump runs for 3 minutes


Key "5" is a longer program where the pump runs for 10 minutes.

Key "2" is a program for "Boil out" Here, the set point temperature will be set to 90°C, and the option is to clean the tub and heat-elements with hot water and soap. **Warning! Water must not be led through the pump but must be drained into a separate container after cleaning! Before using Boil out, the tub must be completely drained of oil. When the boil out is finished, the tub must be completely drained of cleaning water and dried completely before refilling with oil.**



When the program is finished and the oil is in the tub, you can press key "6", after which the fryer goes into active mode. If you want to switch off the machine, press the "O" key.

3.8.2 Preparation of the filter system



A. Draining bucket
B. Bottom filter
C. Filter PAD
D. Frame for filter
E. Coarse filter
F. Lid

1. Filter PAD (C) must be changed as needed. Estimated consumption 1-3 pcs. per week depending on the fryer's operation time. (Filter package with 50 pcs. item number 04-21068) Pay attention to place the filter correctly, there is a coarse and a fine side. The fine side must face downwards.
2. Place the bottom filter (B) in the draining bucket (A) as shown in fig. 1
3. Then place the Filter PAD (C) as shown in fig. 2
4. Mount frame for filter (D) fig. 3
5. Fit coarse filter (E) fig. 4
6. Mount Cover (F) fig. 5



Figure 1



Figure 2



Figure 3



Figure 4




Figure 5

1. When the preparation of the filter system has been completed (points 1-6), place the draining bucket in the fryer. See fig. 6 Position the drain pan, so that the flange and connecting pipe fit together. See fig. 7. The pipe, which is mounted in the draining bucket, can be adjusted, as shown in fig. Fig. 7
2. Mount the sleeve on the connection pipe and tighten carefully, using the supplied spanner. See Fig. 8



Figur 6




Figur 7



Figur 8

The system is now prepared for cleaning the oil. Relating to programming see section 3.8.1

3.9 Spare parts



3.9.1 Spare parts list

Fryer ADV 400V 3N~

POS	PRODUCT NUMBER	QTY	QTY	QTY	DESCRIPTION
		Double	Single	Single Split	
1	72-03615	2	1	2	THERMOSTAT LIMITER
2	83-10002	2	1	2	SENSOR PT 100
3	84-00056	6	3	-	Heating element 3 kW, 400V
3	84-00061	6	3	2	Heating element 5 kW, 400V
3	84-00072	6	3	2	Heating element 7 kW, 400V
4	83-41000 (10kW)	2	1	1	Contactor B&J 2NO 40A AC1 230VAC
4	83-41001 (9kW)	2	1	1	Contactor LC1D9P7 9A 230VAC
4	83-41003 (15kW)	2	1	1	Contactor LC1D25P7 25A 230VAC
4	83-41004 (21kW)	2	1	1	Contactor LC1D32P7 32A 230VAC
4	****72-07020	2	1	-	Contactor LC1D25BD 25A 24VDC
4	****72-07027	-	-	2	Contactor LP1K0901BD 9A 24VDC
5	72-07013	2	1	1	POWER SUPPLY 240VAC / 24VDC 130W
6	72-08003	2	1	2	Controller CTL
7	72-08000	2	1	2	Controller GUI FRYER ADV
7a	*****72-08001	2	-	-	Controller GUI FRYER ADV + OIL CLEAN
8	72-00152	4	2	2	SSR 3,5-32VDC 24-510VAC 95A
9	72-07015	2	1	2	USB DONGLE LP-24-USB3.0-S01
10	83-41013	2	1	1	Switch, 4-POLE telux 50A
11	***84-00622	2	1	2	BALL VALVE 1" M/M MS
11	****84-00058	2	1	2	BALL VALVE 3/4" M. T-GREB
12	72-05511	1	-	-	FILM FOR TOUCH SCREEN FRYER ADV DF/DT
12	72-05513	-	1	-	FILM FOR TOUCH SCREEN FRYER ADV SF/ST
12	72-05514	-	-	1	FOLIE FOR TOUCH SKÆRM FRYER ADV SF/ST Split
13	84-00070	1	1	-	FRY BASKET 1/1 FKE16-
14	84-00071	2	2	2	FRY BASKET 1/2 FKE16-

* either 2 1/2 baskets or 1 1/1 basket per vat

** Applies only to automatic raise/lowering system variants

***Floormodels

****Counter Top models

*****FRYER ADV + OIL CLEAN

Fryer ADV 230V 3~

POS	VARE NUMMER	STK	STK	STK	BENÆVNELSE
		Double	Single	Single Split	
1	72-03615	2	1	2	THERMOSTAT LIMITER
2	83-10002	2	1	2	SENSOR PT 100
3	84-00057	6	3	-	Heat element 3 kW 230V
3	84-00062	6	3	2	Heat element 5 kW 230V
4	83-41000 (10kW)	2	1	1	CONTACTOR B&J 2NO 40A AC1 230VAC
4	83-41003 (9kW)	2	1	1	CONTACTOR LC1D25P7 25A 230VAC
4	83-41004 (15kW)	2	1	1	CONTACTOR LC1D32P7 32A 230VAC
4	****72-07020	2	1	-	Contactor LC1D25BD 25A 24VDC
4	****72-07027	-	-	2	Contactor LP1K0901BD 9A 24VDC
5	72-07013	2	1	1	Power supply 240VAC / 24VDC 130W
6	72-08003	2	1	2	Controller CTL
7	72-08000	2	1	2	Controller GUI FRYER ADV
7a	****72-08001	2	-	-	Controller GUI FRYER ADV + OIL CLEAN
8	72-00152	4	2	2	SSR 3,5-32VDC 24-510VAC 95A
9	72-07015	2	1	2	USB DONGLE LP-24-USB3.0-S01
10	83-41013	2	1	1	Switch 4-POL telux 50A centermontage
11	***84-00622	2	1	2	Ball valve 1" M/M MS
11	****84-00058	2	1	2	Ball valve 3/4" M. T-GREB
12	72-05511	1	-	-	Protection for TOUCH SCREEN FRYER DF/DT
12	72-05513	-	1	-	Protection for TOUCH SCREEN FRYER SF/ST
12	72-05514	-	-	1	Protection for TOUCH SCREEN FRYER ADV SF/ST Split
13	84-00070	1	1*	-	FRY BASKET 1/1 FKE16-
14	84-00071	2	2*	2	FRY BASKET 1/2 FKE16-

* either 2 1/2 baskets or 1 1/1 basket per vat


** Applies only to automatic raise/lowering system variants

***Floormodels

****Counter Top models

*****FRYER ADV + OIL CLEAN


3.9.2 Spare parts list Automatic Raise/lowering for Fryer ADV SF



POS	Item no.	pcs	Description
1	84-00320	1	SUSPENSION FOR ½ BASKET RIGHT
2	84-00323	1	SUSPENSION FOR ½ BASKET LEFT
3	*84-00330	1	SUSPENSION FOR 1/1 BASKET
4	84-25044	2	LIFTING BAR FOR H/S
5	84-25048	2	Lock bolt for actuator H/S
6	84-25046	2	Socket for galvanic isolation H/S
7	84-25043	2	CONTROL HOUSING FOR ACTUATOR H/S
8	83-10076	2	ACTUATOR FRYER ADV RAISE/LOWER
9	84-00461	2	HOUSING FOR ACTUATOR H/S

*Alternative


3.9.3 Spare parts list Automatic Raise/lowering for Fryer ADV DF



POS	Item no.	Pcs.	Description
1	84-00323	1	SUSPENSION FOR 1/2 BASKET LEFT
2	84-00320	1	SUSPENSION FOR 1/2 BASKET RIGHT
3	84-25044	3	LIFTING BAR FOR H/S
4	84-00330	1	SUSPENSION FOR 1/1 BASKET
5	84-25043	3	CONTROL BOX FOR ACTUATOR H/S
6	84-25046	3	Socket for galvanic isolation
7	84-25048	3	Lock bolt for actuator H/S
8	84-00461	3	HOUSING FOR ACTUATOR H/S
9	83-10076	3	ACTUATOR FRYER ADV RAISE/LOWER


number depends on configuration and baskets

3.9.4 Spare parts list Automatic Raise/lowering for Fryer ADV SFS



POS	Item no	pcs	Description
1	84-25126	1	SUSPENSION F ½ BASKET, LEFT FRYER ADV SPLIT
2	84-25127	1	SUSPENSION F ½ BASKET, RIGHT FRYER ADV SPLIT
3	84-25044	2	LIFTING BAR FOR H/S
4	84-25048	2	Lock bolt for actuator H/S
5	84-25046	2	Socket for galvanic isolation H/S
6	84-25043	2	CONTROL HOUSING FOR ACTUATOR H/S
7	84-00461	2	HOUSING FOR ACTUATOR H/S
8	83-10076	2	AKTUATOR FRYER ADV HÆV/SÆNK

3.9.5 Spare parts list oil cleaning system




POS	PRODUCT NUMBER	QTY	Description
1	15-00041	1	COMPLETE DRAIN PIPE FOR OIL CLEANER
2	84-25159	2	PIPE BETWEEN 3-WAY VALVE AND TANK FRYER
3	84-25160	1	PIPE BETWEEN PUMP AND VESSEL FRYER
4	84-00634	3	COMPRESS. FITTING 90° Ø12X3/8 STAINLESS
5	84-00637	1	BALL VALVE 3-WAY G3/8" L-BORE STAINLESS STEEL
6	84-25166	1	BRACKET FOR 3-WAY VALVE
7	84-00621	4	COMPRESS. FITTING NIPPLE Ø12X3/8 STAINLESS
8	84-25162	1	BRACKET FOR HANDLE FOR 3-WAY VALVE
9	84-00630	1	WELDING NIPPLE G1"X125MM
10	84-00613	2	PIPE HOLDER 316F Ø12

POS	PRODUCT NUMBER	QTY	Description
11	84-25158	1	BRACKET FOR PIPE HOLDER
12	84-25200	1	PIPE SYSTEM BETWEEN FILTER AND PUMP
13	84-25165	1	COMPLETE HANDLE FOR FRYER OIL CLEANER
14	84-25202	1	KEY TO ORBIT
15	84-25204	1	COMPLETE PIPE BETWEEN DETAP. BUCKET AND PIPE SYSTEM
16	74-00082	1	PUMP EP NEOS 3/4 (0.22KW/230V)
17	84-00635	1	SOCKET, REDUCTION 3/4" - 3/8" STAINLESS
18	84-00636	1	TIP MUFFLER 3/4 -3/8 STAINLESS
19	74-00067	1	CHECK VALVE STAINLESS 3/8" M/M PTFE SEALING
20	78-04310	4	SCREW,SET-M5X10 A2
21	78-04615	4	DISC, FACET Ø5 A2
22	84-25183	1	DRAIN PAN OIL FILTER PAD SYSTEM
23	84-00039	1	O-RING Ø19.6X2.4 FPM75 FK- B

Filter package with 50 pcs. item number 04-21068


3.9.6 IT-system




POS.	Pcs.	Varenummer	Description	System
1	2	83-10013	TRAFO 440/230V STE100/4/23	IT SYSTEM
1	2	72-07036	TRAFO 440/230V STE500/4/23	IT SYSTEM w. oilcleaning
2 page 28	2	83-09999	Sencor PT100 KL B Ø6X115/300 90° 3L 2,0 M	IT SYSTEM with/without oil- cleaning
	2	84-41014	Contactor B&J aux 1NO+1NC R25, R40, R63	IT SYSTEM with/without oil- cleaning

4 Electrical diagram


4.1.1 Fryer ADV 400V 3N~ / Fryer ADV 230V 3~ (Overview)




4.1.2 9kW, 15kW, 21kW




4.1.3 Single controller



4.1.4 Heating section




4.1.5 Single oil clean




Project title:	Fryer ADV - Generic schematic	Project no.:	Project rev.:	Page
Customer:	DCC:			4
Page title:	Dwg. no.:			1:1
File name:	Eng. (proj/page):		Page rev.:	Previous page: 3
	Appr. (date/init):		Last print:	Next page: 5
Page ref.:				Last edit: 18/03/2024 Total no. of pages: 10


4.1.6 Double oil clean




4.1.7 2x5kW, 2x7kW




4.1.8 Split controller



4.1.9 Split heating section



4.1.10 Split oil clean




4.1.11 Component overview Fryer ADV 400V 3N~


Fryer ADV 400V 3N~									
Function	Component	9kW	15kW	21kW	10kW	14kW	Function	Component	Component
Main Switch	.Q01	M10H (20A)	N35F (50A)	N35F (50A)	N35F (50A)	N35F (50A)	Control card	A1	CTL Print
		83-41011	83-41013	83-41013	83-41013	83-41013	Control card	A3	72-08003
Safety contactor	.Q3	LC1D0987	LC1D2597	LC1D3287	R40-20-230	R40-20-230	Graphical interface	A2	GUI PRINT
		83-41001	83-41003	83-41004	83-41000	83-41000	Graphical interface	A4	72-08000*
Safety contactor	.Q4	-	-	-	R40-20-230	R40-20-230	-	-	-
Power Supply	.T1	EC5130U524	EC5130U524	EC5130U524	EC5130U524	EC5130U524	Motor left	.M1	L431
		72-07013	72-07013	72-07013	72-07013	72-07013	Motor right	.M2	83-0803
Supply plug	.N01	Customer	Customer	Customer	Customer	Customer	Latch SSR L1	.Q1	83-0803
Supply cable	.W01	5G15 / 3.5m	5G2.5 / 3.5m	5G4.0 / 3.5m	5G2.5 / 3.5m	5G4.0 / 3.5m	Latch SSR L3	.Q3	3.5-32/DC 95A
		72-03672	72-03674	72-03545	72-03674	72-03545			3.5-32/DC 95A
		9kW	15kW	21kW	10kW	14kW			3.5-32/DC 95A
Function	Component						Board to board connector		
Heating element	.E1	3kW / 400V	5kW / 400V	7kW / 400V	5kW / 400V	7kW / 400V	W1	HCD5"	HCD5"
		84-00056	84-00061	84-00072	84-00061	84-00072	W2	72-07011	72-07011
Heating element	.E2	3kW / 400V	5kW / 400V	7kW / 400V	5kW / 400V	7kW / 400V	Power cable	W3	72-07029
		84-00056	84-00061	84-00072	84-00061	84-00072	Signal cable	W4	450/7.5 / 1.8m
Heating element	.E3	3kW / 400V	5kW / 400V	7kW / 400V	5kW / 400V	7kW / 400V	Board to board connector	W5	-
PT100 sensor	.R1	83-10002	83-10002	83-10002	83-10002	83-10002	USB cable	W6	HCD5"
PT100 sensor	.R2	-	-	-	83-10002	83-10002			72-07011
Safety thermostat	.F1	55.33542.070	55.33542.070	55.33542.070	55.33542.070	55.33542.070	USB connector	.X1	LP-24-USB-P01
Safety thermostat	.F2	72-03615	72-03615	72-03615	72-03615	72-03615	USB connector	.X2	LP-24-USB-P01
Reed relay	.F3	MS-228M-6-4	MS-228M-6-4	MS-228M-6-4	MS-228M-6-4	MS-228M-6-4	Reed relay	.F2	MS-228M-6-4
		72-00022	72-00022	72-00022	72-00022	72-00022	Reed relay	.F3	MS-228M-6-4
		-	-	-	-	-		-	72-00022
Function	Component	-G1	-G2	-G3	-G4	-G5			
Latch contactor	.Q1	LC1D259D	LC1D259D	LC1D259D	LC1D259D	LC1D259D	LP1K0901BD		
		72-07020	72-07020	72-07020	72-07020	72-07020	LP1K0901BD		
Latch contactor	.Q2	-	-	-	-	-	LP1K0901BD		
Mechanical interlock	.F1	-	-	-	LAD9V2	-	72-07027		
Pump	.G1	EP NEOS 3/4							
		74-00082	74-00082	74-00082	74-00082	74-00082	74-00082		
Plugs per Control Card	Component	Component	Component	Component	Component	Component	Component	Component	Component
Power Supply	.POWER	72-07003							
SSB and PT100	BOTTOM HEAT	72-07004							
Oil clean	.AUX	72-07000							
Contactor control	.RELAY	72-07001							


4.1.12 Component overview Fryer ADV 230V 3~


Fryer ADV 230V 3~						
Function	Component	9kW	15kW	10kW	-Q1	-Q2
Main Switch	.Q11	N33F (50A)	N33F (50A)	N33F (50A)		
		83-41013	83-41013	83-41013		
Safety contactor	.Q3	LC1D25F7	LC1D25F7	R4D-20-230	Control card	A1
		83-41003	83-41004	83-41000		
Safety contactor	.Q4			R4D-20-230	Graphical interface	A3
				83-41000		
Power Supply	.T1	EC5130U524	EC5130U524	EC5130U524	Graphical interface	A2
		72-07013	72-07013	72-07013		
Supply plug	.X11	Customer specific	Customer specific	Customer specific	Motor left	A4
		4G6.0 / 3.5m	4G6.0 / 3.5m	4G6.0 / 3.5m		
Supply cable	.W11	72-03528	72-03528	72-03520	Motor right	.M1
					Latch SSR L1	.M2
						.Q1
					Latch SSR L3	.Q3
						3.5-32VDC 95A
						3.5-32VDC 95A
						3.5-32VDC 95A
Function	Component	9kW	15kW	10kW	-E1	-E2
Heating element	.E1	3kW / 230V	5kW / 230V	5kW / 230V	Board to board connector	W1
		84-00057	84-00062	84-00062		HCSD 5"
Heating element	.E2	3kW / 230V	5kW / 230V	5kW / 230V	USB cable	W2
		84-00057	84-00062	84-00062		HCSD 5"
Heating element	.E3	3kW / 230V	5kW / 230V	5kW / 230V	Power cable	W3
		84-00057	84-00062	84-00062		1.8m
PT100 sensor	.R1	83-10002	83-10002	83-10002	Signal cable	W4
						As supply cable
PT100 sensor	.R2			83-10002	Board to board connector	W5
						4G6.75 / 1.8m
Safety thermostat	.F1	55.33542.070	55.33542.070	55.33542.070	As supply cable	W6
		72-03615	72-03615	72-03615		2.2m
Safety thermostat	.F2			55.33542.070	USB connector	X1
				72-03615		LP-24-USB-P01
Reed relay	.F3	MS-228M-6-4	MS-228M-6-4	MS-228M-6-4	USB connector	X2
		72-00022	72-00022	72-00022		LP-24-USB-P01
					Reed relay	.F2
						MS-228M-6-4
						MS-228M-6-4
						MS-228M-6-4
Function	Component	.G1	.G2	.G3		
Latch contactor	.Q1	LC1D25F0	LC1D25F0	LP1K0901BD		
		72-07020	72-07020	72-07027		
Latch contactor	.Q2		LC1D25F0	LP1K0901BD		
			-	72-07020		
Mechanical interlock	.F1		LA09V2	72-07027		
			-			
Pump	.G1	EP NEOS 9/4	EP NEOS 9/4	EP NEOS 9/4		
		74-00082	74-00082	74-00082		
Plugs per Control Card	Component	Part no.				
Power Supply	POWER	72-07003				
SSR and PT100	BOTTOM HEAT	72-07004				
Oilclean	AUX	72-07000				
Contactor control	RELAY	72-07001				

4.1.13 IT System 400V 3~












Project title:	Fryer ADV - IT schematic	Project rev.:	Page
Customer:		DCC:	3
Page title:	Heating section	Dwg. no.:	1.1
File name:	Electrical - Fryer ADV - Schematic - IT	Page rev.:	2
Page ref.:	[Single heating section]	Eng. (proj/page):	4
	Apr. (date/lnit):	Last print:	18/03/2024
		Next page:	19/03/2024
		Last edit:	15/09/2022
		Total no. of pages:	10









Project title:	Fryer ADV - IT schematic		
Customer:	Project no.:		
Page title:	DCC:	Page rev.:	Page:
Supply	Dwg. no.:	Previous page:	1:1
File name: Electrical - Fryer ADV - Schematic - IT	Eng. (proj/page):	Next page:	5
Page ref.: [2x5kW, 2x7kW]	Appl. (date/lnit):	Last edit:	18/03/2024
		Total no. of pages:	10







4.1.1 Component overview IT System 400V 3~

Fryer ADV 400V 3~									
Function	Component	9kW	15kW	21kW	10kW	14kW	Function	Component	Part no.
Main Switch	Component .Q01	M10H/20A 83-41011	N33F (50A) 83-41013	N33F (50A) 83-41013	N33F (50A) 83-41013	N33F (50A) 83-41013	Control card	.A1	CT1 Print 72-08003
Safety contactor	Component .Q3	LC1D09P7 83-41001	LC1D25P7 83-41003	LC1D25P7 83-41004	LC1D25P7 83-41000	LC1D25P7 83-41000	Control card	.A3	CT1 Print 72-08003
Safety contactor	Component .Q4	-	-	-	R40-20-230	R40-20-230	Graphical interface	.A2	GUI PRINT 72-08000*
Safety aux. contactor	Component .Q3 add on	-	-	-	R40-20-230	R40-20-230	Graphical interface	.A4	GUI PRINT 72-08000*
Safety aux. contactor	Component .Q4 add on	-	-	-	R40-20-230	R40-20-230	Motor left	.M1	LA31 83-10803
Power Supply	Component .T1	ECS130U524 72-07013	Motor right	.M2	LA31 83-10803				
Transformer 240V/24V Without oil clean	Component .T2	380-230 83-10013	380-230 83-10013	380-230 83-10013	380-230 83-10013	380-230 83-10013	Latch SSR L1	.Q1	3.5-32VDC 95A 72-00152
Transformer 240V/24V With oil clean	Component .T2	380-230 72-07036	380-230 72-07036	380-230 72-07036	380-230 72-07036	380-230 72-07036	Latch SSR L3	.Q3	3.5-32VDC 95A 72-00152
Supply plug	Component .W01	Customer specific 4G1.5/3.5m 72-03672	Customer specific 4G1.5/3.5m 72-03674	Customer specific 4G1.5/3.5m 72-03545	Customer specific 4G1.5/3.5m 72-03674	Customer specific 4G1.5/3.5m 72-03545	Board to board connector	.W1	HSD 5" 72-07011
Supply cable	Component .W01	4G1.5/3.5m 72-03672	4G1.5/3.5m 72-03674	4G1.5/3.5m 72-03545	4G1.5/3.5m 72-03674	4G1.5/3.5m 72-03545	USB cable	.W2	HSD 5" 72-07011
							Power cable	.W3	72-07029 2.2m
							Signal cable	.W4	As supply cable 1060.75 / 2.2m
							Board to board connector	.W5	As supply cable 1060.75 / 1.8m
Heating element	Component .E1	3kW/400V 84-00056	5kW/400V 84-00056	7kW/400V 84-00056	5kW/400V 84-00056	7kW/400V 84-00056	USB cable	.W6	HCSD 5" 72-07011
Heating element	Component .E2	3kW/400V 84-00056	5kW/400V 84-00061	7kW/400V 84-00061	5kW/400V 84-00061	7kW/400V 84-00061	USB connector	.X1	LP-24-USB-P01 72-07014
Heating element	Component .E3	3kW/400V 84-00056	5kW/400V 84-00061	7kW/400V 84-00061	5kW/400V 84-00061	7kW/400V 84-00061	USB connector	.X2	LP-24-USB-P01 72-07015
PT100 sensor	Component .R1	84-00056	84-00061	84-00072	84-00061	84-00072	Reed relay	.F2	MS-228M-6-4 72-00022
PT100 sensor	Component .R2	-	-	-	83-09899	83-09899	Reed relay	.F3	MS-228M-6-4 72-00022
Safety thermostat	Component .F1	55.33542.070 72-03615	55.33542.070 72-03615	55.33542.070 72-03615	55.33542.070 72-03615	55.33542.070 72-03615	*72-08001 if oil clean is installed		
Safety thermostat	Component .F2	MS-228M-6-4 72-00032	*72-08001 if oil clean is installed						
Reed relay	Component .F3	MS-228M-6-4 72-00032	*72-08001 if oil clean is installed						
Function	Component	.G1	.G2	.G3	.G4	.G5	Plugs per Control Card	Component	Part no.
Latch contactor	Component .Q1	LC1D25BD 72-07020	Power Supply	.POWER	72-07003				
Latch contactor	Component .Q2	-	-	-	LC1D25BD 72-07020	LC1D25BD 72-07020	SSR and PT100	.BOTTOM HEAT	72-07004
Mechanical interlock	Component .F1	-	-	-	LA09V2 72-07027	LA09V2 72-07027	Oil clean	AUX	72-07000
Pump	Component .G1	EP NEOS 3/4 74-00082	Contactor control	.RELAY	72-07001				

Cleaning

4.2 General

Before using the appliance for the first time, wipe all surfaces that will be in contact with food with a damp cloth. Do not use cleaning products that contain acid.

4.3 Cleaning during operation

Make sure that the tabletop, front and other surfaces are clean at all times. Wipe with a slightly damp cloth.





Remember to use personal safety equipment, see 2.1

4.4 Daily cleaning


The fryer should be cleaned daily.

The fryer is equipped with a "Boil out" function.

Drain oil from the tub and fill with cleaning water. Key "2" is a program for "Boil out", the set point temperature will be set to 90°C, and the option is to clean the vessel and possibly heaters with hot water and soap. Warning! Before using Boil out, the tub must be completely drained, no oil left. When the Boil out is finished, press the "O" key and the fryer is switched off. The tub must be completely drained of cleaning water and dried completely before refilling with oil.



WARNING! After cleaning with Boil out, remember to drain the tub from water and soap and dry afterwards. There must be no water in the tub when refilling with oil.



Switch the fryer off and allow to cool. For automatic raise/lowering fryers, standby will then activate and the baskets will lower. Open the drain tap and allow the oil to run into the drain tub.



Remove baskets and mounting (where applicable) from the fryer.



Raise the heating section and tip it backwards.



Allow the heating section to be supported on the retainer.



Cleaning products must not be used on surfaces that come into contact with food. If this is unavoidable, rinse very thoroughly with clean water.



Wipe down the heating section with a damp cloth.




Exercise particular caution in the area near the magnetic contact. Regular cleaning is particularly important here.



Carefully wipe the front section and the display with a damp cloth.




Place the heating section and basket back in position.



Clean the filter and drain tub.

5 Service

Find out if it is possible to correct the fault by following the instructions in the troubleshooting chart. If not, contact your dealer or www.fki.dk for assistance.



When contacting service for assistance, please have the following information ready:


- Sequential serial number located on the back of the appliance.
- Type and model name are in the same position.

The machine plate is on the back of the appliance (see picture).



Before commencing repair work, the appliance must always be switched off and disconnected from the power source. Both diodes on the front must have gone out before accessing electrical components.

To make it easy to service the FRYER ADV, most electrical parts are mounted in a closed system behind the front panel. Remove the front section using the screws that become visible when the doors are opened (shown in red below). Because of the displays in the front, exercise caution after removing the screws. It is advisable to place the front section on its front, with the front side facing the top of the doors (only applicable to twin vat/2 door models). This allows access to all the control components.



After completing service work on the FRYER ADV, check and reattach all cables, making sure that they are secured and will not be trapped.

6 Disposal

6.1 Packaging

The packaging should not be left in the environment but should be disposed of in accordance with local regulations.

6.2 When the appliance is no longer required

FRYER ADV is labelled with a recycling symbol in accordance with Danish Executive Order 148 of 8 February 2018 (Electronic Waste Executive Order/Elektronikaffaldsbekendtgørelsen). WEEE2 directive 2012/19/EU

This means that you must dispose of it in accordance with your municipality's regulations, e.g. in a container set up for this purpose at the municipality's recycling centre when the appliance is worn out.



7 EU DECLARATION OF CONFORMITY



FKI Fast Food Teknik a/s

EU DoC ID: FKI 012
Verninge, 13. december 2021

EU DECLARATION OF CONFORMITY

We FKI Fast Food Teknik a/s declares under our sole responsibility that the product Fryer Advanced with

Type Code.:
ADF-21

are in conformity with the following directive(s), standard(s) or other normative document(s), provided that the products are used in accordance with our instructions.

Directives	Standards
Machine Directive 2006/42/EC	EN 12100:2010 EN 60335-1:2012 + AC:2014 + A11:2014 EN 60335-2-37:2002
Electromagnetic Compatibility Directive 2014/30/EU	EN 55014-1:2006 + A1:2009 + A2:2011 EN 55014-2:1997 + A1:2001 + A2:2008
WEEE Directive 2012/19/EU RoHS Directive 2011/65/EU	

Regulations	Standards
Food Contact Materials 1935/2004	
Good Manufacturing Practice 2023/2006	N/A

Date	Issued by
13/12-2021	 Søren Poulsen
Søren Poulsen - Managing Director	

FKI Fast Food Teknik a/s only vouches for the correctness of the English version of this declaration. In the event of the declaration being translated into any other language, the translator concerned shall be liable for the correctness of the translation.

Byghøjvej 5 · Verninge · DK-5690 Tommerup
Tel. +45 64 75 10 66 · Fax +45 64 75 10 88 · CVR no. 1472 8287 · www.fki.dk



FKI Fast Food Teknik a/s

Byghøjvej 5 · Vernerup · DK-5690 Tommerup · Denmark · Tel. +45 6475 1066 · info@fki.dk ·